


180.1910.2
180.1910.2 BH
180.1910.2 BL
180.1910.2 KU

VARIANTI STANDARD / BH / KU
STANDARD / BH / KU MODELS




141.602.17

180.602.49

180.602.49

180.620.35
22/90° NERO/BLACK

VARIANTE BL
BL MODEL




141.602.17

180.602.49

180.602.49

180.620.34
6.0/90° NERO/BLACK

VARIANTI STANDARD / BH / BL
STANDARD / BH / BL MODELS




180.601.2

180.232.5

VARIANTE KU
KU MODEL

SENZA CONNETTORE
WITHOUT CONNECTOR



180.4.8

180.614.7

68.602.9

180.602.44

180.602.44

180.1506.26

180.1304.55

Assemblare 180.1617.6 con
SELON 628
Coppia di serraggio 15 Nm

180.1617.6

180.1709.1
MARCATURA LASER

180.1603.18

180.1603.18

180.1604.21

180.1504.76
LOXEAL 56-03

180.218.152

180.1504.73

180.602.30

180.1304.87

300.1902.23

174.507.24



172.602.16

300.1902.23

284.602.82

180.1904.5
NERO/BLACK

180.107.70



POSIZIONE ASSEMBLAGGIO
180.1904.5 E 180.1304.87

SOLO PER KIT
FOR KIT ONLY

75.1003.23

142.602.18

180.306.1 x 2

180.602.30

180.602.48

180.602.50 x 2

180.602.106

180.1009.1 x 2

180.1603.16 x 2

180.1603.21 x 2

280.507.8

COME SI ORDINA / HOW TO ORDER
Kit ricambio
Spare parts kit **180.302.31**